

VIP Products That Appear to Have Excessively High Levels of Pb (lead)

Test Date	Vendor	Description	Model	UPC	Max. allowance (PPM)	Sample # (each sample tested twice)		
						1	2	3
						Pb in PPM	Pb in PPM	Pb in PPM
2/29/08	VIP	Tuffie Bone Red Small	JRBRP	180181020117	600	1241/1125	1449/1515	802/1429
2/29/08	VIP	Tuffie Bone Red Large	UBRP	180181002014	600	1598/1557	1191/1207	
2/29/08	VIP	Tuffie Stingray	USTINGSTR	180181008016	600	1767/1735	1525/1599	
2/29/08	VIP	Tuffie Boomerang Red Small	JRBRP	180181016011	600	1031/864	973/1351	
2/19/08	VIP	Tuffie Boomerang Pink Small	JRBRPL	180181016028	600	1228/1330	1155/1257	
2/29/08	VIP	Tuffie Boomerang Red Large	UBRRP	180181006012	600	1501/1454	1454/1110	
2/29/08	VIP	Tuffie Boomerang Pink Large	UBRPL	180181006029	600	1212/1249	1096/806	
2/29/08	VIP	Tuffie Starfish	USTARSTAR	180181009013	600	1607/1455	1605/1404	1632/1685
2/29/08	VIP	Tuffie Eel	UEELEEL	180181010019	600	1267/1582	1802/1678	
2/29/08	VIP	Tuffie Ring Red Small	JRRRP	180181011016	600	1127/1128		
2/29/08	VIP	Tuffie Alligator	UALIALI	180181020018	600	2710/1810	1606/1390	
2/29/08	VIP	Tuffie Ring Red Large	URRP	180181001017	600	1723/1414	1239/1409	1281/1622
2/29/09	VIP	Tuffie Tug Y1 L	UTWYB	180181005039	600	1360/1041		
2/29/08	VIP	Tuffie Lobster Red Large	ULOBLOB	180181020148	600	1319/1540	1578/1877	
2/29/08	VIP	Tuffie Octopus Small	JROCTSM	180181007019	600	2001/1531	1402/2206	

* 1-3 different samples were tested, depending on availability. Each sample was tested twice, once on the front, once on the back, each on opposite sides. Each test was approximately one minute in duration.

* Usually, the Pb levels were within similar ranges for each product, although occasionally there were larger gaps, sometimes due to the angle the analyzer was tilting, or the thickness of the product where it was tested. For example: on the Tuffie Octopus, each reading showed one number about 500ppm above the other. This reading was from the top of the head of the octopus, the thickest point of the product.